



## USER MANUAL


### ORTEGA LED MUSIC LIGHT

Thank you for purchasing Ortegas USB chargeable Music Light.

Please read this user manual first before using the light. We will introduce some of the important features and operating procedures of this product.

Please keep this manual in a safe place for future reference.


#### PACKAGE CONTENTS



#### SPECIFICATIONS

Item	USB Chargeable LED Music Light
Light Source	OML-S, 4 LEDs / OML-D, 8 LEDs
Power	1 W
Color Temperature	6000 k - 6500 k
Luminous Flux	160 lm
Power Supply	<b>USB RECHARGEABLE - NO BATTERIES OR POWER SUPPLY NEEDED!</b>
Color	Black / Orange
Net Weight	OML-S (75 g) / OML-D (90 g)

#### STRUCTURE DIAGRAM



#### OPERATION

Press the power button, if the LED lights up, you can continue to use it.

If it does not light up, the power may be used out.

Please insert the included USB cable into the USB Interface, then connect it to power source.

After being fully charged, the LED still can be used.

#### Operation

The 3<sup>rd</sup> time short press  
Bend the goose neck

#### Function

Turn off  
Adjust the light angle

#### CAUTIONS & WARNINGS

1. Do not repair, disassemble, or modify the product without approval.
2. Do not place it near any heat sources or in direct sunlight.
3. Please unplug the USB cable when the light is fully charged.
4. Do not touch electrical appliance when wet or when liquids are present.
5. Attach / Clip to flat and secure surface.
6. Please keep the light dry and clean.
7. Clean only with a soft dry cloth and do not use solvents or cleaning solutions.
8. Never overload electrical circuits as it may cause electrical shock or fire.



#### CORRECT DISPOSAL OF THIS PRODUCT

(Waste Electrical & Electronic Equipment).

This marking shown on this product or it's literature, indicate that it should not be disposed of with other household wastes at the end of it's working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of waste and recycle it responsibly to promote sustainable reuse of material resources.

Household user should contact either the retailer where they purchased this product, or their local government office for details on proper recycling.


Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial waste for disposal.

Ortega - a brand of Roland Meinel Musikinstrumente GmbH & Co.KG  
Musik-Meinel-Str. 1 | 91468 Gutenstetten, Germany | www.ortegaguitars.com  
Designed in Germany | Manufactured in P.R. China




## BEDIENUNGSANLEITUNG

### ORTEGA LED MUSIC LIGHT




#### PACKUNGSINHALT



#### SPEZIFIKATIONEN

Artikel	Wiederaufladbares, mobiles LED-Licht
Lichtquelle	OML-S, 4 LEDs / OML-D, 8 LEDs
Leistung	1 W
Farbtemperatur	6000 k - 6500 k
Lichtstrom	160 lm
Energieversorgung	<b>USB-AUFLADBAR, KEINE BATTERIEN ODER NETZTEIL NOTWENDIG!</b>
Farbe	Schwarz / Orange
Netto-Gewicht	OML-S (75 g) / OML-D (90 g)

#### BEDIENELEMENTE



#### BETRIEB

Drücken Sie den Power-Knopf - wenn die LEDs leuchten, können Sie die Lichtquelle ganz normal verwenden.

Wenn sie NICHT aufleuchten, muss der fest verbaute Akku mit dem mitgelieferten USB-Kabel aufgeladen werden.

Hierzu können Sie jede USB-kompatible Stromquelle nutzen.

#### Bedienung

Drittes Mal drücken  
Schwanenhals biegen

#### Funktion

Ausschalten  
Beleuchtungswinkel einstellen

#### WARNUNGEN

1. Reparieren, zerlegen oder modifizieren Sie das Produkt niemals eigenmächtig.
2. Stellen Sie es nicht in der Nähe von Wärmequellen oder direkter Sonneneinstrahlung auf.
3. Bitte ziehen Sie das USB-Kabel ab, wenn das Licht vollständig aufgeladen ist.
4. Berühren Sie das elektrische Gerät nicht, wenn es nass ist oder mit Flüssigkeiten in Berührung gekommen ist.
5. Auf eine flache und sichere Oberfläche klammern.
6. Vor Feuchtigkeit schützen.
7. Nur mit einem trockenen Tuch reinigen (z.B. Mikrofiber).
8. Überlasten Sie niemals elektrische Stromkreise, da dies einen elektrischen Schlag oder einen Brand verursachen kann.



#### KORREKTE ENTSORGUNG DIESES PRODUKTES

(Elektro- und Elektronik-Altgeräte).

Dieses Symbol auf dem Produkt oder in der Beschreibung weist darauf hin, dass das Produkt nicht mit normalen Haushaltsabfällen entsorgt werden darf.

Um mögliche Schäden für die Umwelt oder die menschliche Gesundheit durch unkontrollierte Abfallentsorgung zu vermeiden, recyceln Sie Altgeräte bitte umweltgerecht - auch um eine nachhaltige Wiederverwendung von Materialressourcen zu fördern.

Besitzer können sich entweder an den verkaufenden Händler wenden oder an ihre kommunalen Abfallwirtschaftsbetriebe, um nähere Einzelheiten zum korrekten Recycling zu erfahren.

Gewerbliche Käufer können sich an ihren Lieferanten wenden. Dieses Produkt sollte nicht mit anderen gewerblichen Abfällen zur Entsorgung gemischt werden.

Ortega - a brand of Roland Meinel Musikinstrumente GmbH & Co.KG  
Musik-Meinel-Str. 1 | 91468 Gutenstetten, Germany | www.ortegaguitars.com  
Designed in Germany | Manufactured in P.R. China